

ProLine

0.5/1/1.5 DFC-9/18-M Spare Part List

Pos. No.	Part No.	Descriptions
DF9.2/1	501-009-020	Housing, Strainer
DF9.3	500-009-030	Gasket, strainer housing
DF9.4	500-009-040	Strainer
DF9.5	500-009-050	Valve Body, Kit includes packing and nut
DF9.6	500-009-060	Trigger, Valve
DF9.7	500-009-070	Trigger, Screw: stainless steel use loctite
DF9.8	500-009-080	Safety lock Nut
DF9.9	500-009-090	Snap Ring
DF9.10	500-009-100	Screw, Adjust: kit, POS: 9.9, 9.10, 9.11
DF9.11	500-009-110	Nut, Lock
DF9.12/1	500-009-121	Nut, Packing
DF9.13/1	500-009-131	Packing, Valve: Viton O-ring 2 needed
DF9.14.8	500-009-141	Cable, Valve 9 "
DF9.14.18	500-009-143	Cable, Valve 18 inch
DF9.14.24	500-009-144	Cable, Valve 24 inch
DF9.15	500-009-150	Spring, Seat Stem
DF9.16	500-009-160	Nut, Seat Stem
DF9.17	500-009-170	Seat Stem, w/viton gasket
DF9.18	500-009-180	O-ring, seat stem
DF9.19	505-009-150	Gasket, Valve extension
DF10.8	501-010-080	Extension Wand, 9 inch: Kit includes cable / spring
DF10.18	501-010-180	Extension Wand, 18 inch:Kit includes cable / spring
DF10.24	501-010-240	Extension Wand, 24 inch: Kit includes cable / spring
DF12	500-012-000	Multi-Nozzle, Assembly incl: CC tip straw
DF9.19	505-009-150	Gasket for VE and Tip holder
DF12.3	500-012-030	Tip Holder, Multi-Nozzle , C&C Tip
DF12.4	500-012-040	Gasket, TIP
DF12.6	500-012-060	Tip, CC
DF12.7	500-012-070	Retainer, Tip
DF12.8	935-018-000	Gasket, for CC straw
DF12.9	500-012-090	Crack & Crevice (C&C) Straw
DF12.10	500-012-100	C&C Straw with O-Ring
DFC-8/0	501-000-083	Valve Assembly with 4/way tip, 9"
Drip Free W/Cable	501-000-183	Valve Assembly with 4/way tip, 18"
	501-000-242	Valve Assembly with 4/way, 24"
	501-015-100	Pump/Tank Service Kit: Proline (1.7, 1.11, 1.13, 2.2x2, 4.1, 8.2)
	501-015-110	Pump/Tank Service Kit (serial no. start with T) (1.11, 1.13, 1.7, 2.2x5, 4.1/1, 8.2)
	501-016-030	Valve Service Kit (9.13/1x2, 9.3x2, 9.18, 9.19x2, 12.4, 12.8)