

Care and Maintenance

- As the drying of gel could block the flow for the next use, always leave the gel cartridge inside the compartment after each use or even when the gel is used up but a new cartridge is not replaced yet.
- 2. Maintenance is not necessary as long as the drying of gel does not happen.
- 3. The only care to be required is cleaning. All the parts of gun can be socked and washed in the warm water with detergent.
- 4. When there is air bubble in the gel cartridge, it may occur that no gel comes out even pulling trigger several times. In this case, just push forward the cartridge from the base by 2 thumbs and repeat this movement, the air bubble will be driven out and regular flow continues. Plunger can do the same job of expelling the air bubble out of the cartridge.

Guarantee

AIROFOG MACHINERY CO., LTD. (called AIROFOG) guarantees Airofog Gel Gun to be free of defects in materials or workmanship to the original purchaser for a period of one (1) year, on labour and parts which are not subject to usual wear.

During this period, AIROFOG will replace and/or repair the parts with material and/or manufacturing faults (on the exclusive judgement of our technical department) free of charge.

The despatch and return expenses will be borne by the customer.

The guarantee does not cover any damage occurred during transport or by incorrect handling, tempering, improper use, the use of non-recommended products and so on.

Under no circumstances will AIROFOG be liable for damages due to improper use or application. Under no circumstances will AIROFOG be responsible for damages done to any property or persons.

4 Gel Gun: V2018-04