

PUFF DUSTER SPARE PART LIST

| Pos. no. | Part no. | Description |
|-----------------|-----------------|--|
| 1 | 602-001-000 | Puff Bulb |
| 2 | 602-002-001 | Check Valve Assembly (3,4,5,6), airofog |
| 3 | 602-002-010 | Check Valve Cover |
| 4 | 602-002-020 | Check Valve Seat |
| 5 | 602-002-030 | Check Valve Spring |
| 6 | 602-002-041 | Valve Body, airofog |
| 7 | 602-002-050 | O-Ring 22x2.5 Nitrile |
| 7/1 | 412-017-000 | O-Ring |
| 8 | 602-003-000 | Supply Tube |
| 9 | 602-004-000 | Discharge |
| 11 | 602-006-010 | Rod Assembly |
| 12 | 602-005-000 | Extension Hose cpl. (13x2,14x2,15) |
| 13 | 602-005-010 | Hose Connector |
| 13/1 | 602-005-040 | Nozzle Adapter |
| 14 | 602-005-020 | Hose Holder |
| 15 | 602-005-030 | Hose, 250mm |
| 15/1 | 602-009-120 | Hose 4ft length |
| 16 | 602-009-000 | Extension Tube with Nozzle (13/1,13,14x2,15/1) |
| 19/2 | 602-007-020 | Bottle |
| 20 | 602-008-000 | Extension Assembly (12, 21) |
| 21 | 602-008-020 | Extension Discharge Assembly (22, 23) |
| 22 | 602-008-030 | Extension Handle |
| 23 | 602-008-040 | Extension Lance |
| 25 | 602-010-000 | Carrying Pouch |
| 26 | 602-602-000 | Instruction Manual |
| | 601-021-000 | Belt (optional) |