
Use Instructions:

1. When using BAS for the first time or if have not used it for a while, check all parts in good condition (fig. 1).
2. Unscrew the bottle cap (fig. 2). Make sure the ball valve is in close position.
3. Fill in solution.
Never fill up solution bottle over the maximum level (0.5 l/pint) (fig.3).
4. Paste the gasket inside the bottle cap (fig. 4), screw the cap onto the bottle evenly and firmly, close the bottle cap tightly. Then unscrew the protective cap (fig. 5).
5. Insert charger (8g or 12g) into the charger holder (fig. 6).
6. Screw the charger holder onto the inlet valve unit, the charger content will be released into the BAS bottle with a hissing sound heard.
Each filing uses one 8g or maximum one 12g charger.
7. Unscrew the charger holder and charger (while unscrewing the light hissing sound is normal). Remove and discard the empty steel charger which can be recyclable as scrap metal.
8. Screw in the protective cap, open the ball valve (fig. 7).
9. Hold the BAS upright, press the trigger to spray (fig. 8).

After application, before opening bottle cap, the pressure inside the bottle must be released firstly. Press the trigger to allow the remaining pressure inside the bottle escapes.

Non-threaded cartridge (charger)



	<u>Dimensions (8g)</u>	<u>Dimensions (12g)</u>
Overall Length (A):	66mm/2.6in (Max.)	84mm/3.3in (Max.)
Body Diameter (B):	18.7mm/ 0.7in(Max.)	18.7mm/0.7in (Max.)
Neck Diameter (C):	8.7mm/0.3in(Max.)	8.7mm/0.3in (Max.)

