

BAS Spare Part List

Pos.	Part No.	Description	Pos.	Part No.	Description
1	603-001-000	Bottle	26/3	601-004-013	Nut
2	603-002-000	Cap with Gasket	27	601-004-130	Coiled Hose, Blue
3	603-003-000	Gasket	28	601-004-040	Hose Holder Spring
4	603-004-000	Bottle Cap	28/1	603-004-040	Hose Holder Spring
5	603-005-000	Check Valve Assembly	29	601-007-000	Flexi-Valve Assembly consisting 30-38
6	603-006-000	Tube			
7	603-007-000	Seal	30	601-007-010	Valve Handle
8	603-008-000	Check Valve Seat	31	601-007-020	Valve Body
9	603-009-000	Inlet Valve Assembly (10,11)	32	505-003-014	Spring
10	603-010-000	O-Ring	33	601-007-040	Seat
11	603-011-000	Inlet Valve	34	601-007-060	O-Ring, Viton
12	603-012-000	Lock Nut with Seal (13,14)	35	935-041-000	O-Ring, Viton
13	603-013-000	Seal	36	601-007-070	Seat Sleeve
14	603-014-000	Locking Nut	37	601-007-090	Valve Cup
15	603-015-000	Inlet Valve Assembly	38	601-007-080	Trigger
16	603-016-000	Bottle Cap cpl.	39	601-007-100	O-Ring, Viton
17	603-017-000	Cartridge Holder, 8g	40	601-008-010	Extension, Spiral Wand
17/1	603-017-010	Cartridge Holder, 12g	41	601-009-000	Aerosol Nozzle Set (41/1,41/3,41/4) (optional)
18	603-018-000	Protective Cap			
19	603-019-000	Cartidge 8gr (optional)	41/1	601-009-030	Aerosol Nozzle, White (optional)
19/1	603-019-010	Cartidge 12gr (optional)	41/3	601-009-050	Aerosol Nozzle, Blue
20	605-022-010	Supply Tube	41/4	601-009-070	Aerosol Nozzle, Red (optional)
23	601-003-000	Ball Valve G1/8"	42/1	604-010-012	Extension Crack-Crevice 12cm
24	505-002-020	Gasket	45	603-020-010	Carrying Pouch, Airofog
25	604-025-100	Hose Replacement Kit (26/2x2,26/3x2,27)	46	601-021-000	Belt (optional)
26	601-004-010	Hose Adapter Assembly		601-023-200	Flexi-Valve Service Kit (34,35x2,39x3)
26/1	601-004-011	Adapter		603-023-000	Cap/Inlet Valve Service Kit (3,5,10,13, 20, 24)
26/2	601-004-012	Cutting Ring			