
Thank you for choosing Airofog USA versatile Benjamin Aerosol System (BAS). With this professional tool, you will be able to create a fine aerosol to carry out a better treatment.

Please read the following instructions carefully before using.

Safety measurement

- BAS and chargers are pressure vessels which require particular attention and care.
- Use only BAS original spare parts.
- Do not make any modification or repair to the BAS by yourself.
- Never use the BAS if it is damaged. Always send BAS for a safety check when it falls on floor.
- Do not spray into electric outlets or cable boxes.
- When using the metal extension close to electric outlets, pay attention to avoid the shock hazard.
- Wear personal protective equipment when handling dangerous substances.
- Always return the complete BAS unit for repair.
- Contact the local dealer or manufacturer for spare parts.
- Please keep this instructions booklet. If the BAS is transferred, give the booklet to the new owner.
- Keep BAS and chargers out of the reach of children and persons who may not be aware of dangers involved.
- For safety reasons, the charging inlet of BAS must be in upright direction while charging.
- Open BAS only after the pressure has completely escaped.
- Press the trigger to release pressure inside the bottle until the hissing sound stops.
- Do not expose pressurized BAS to heat (stove, sun and etc.).
- Only use clean water for cleaning. Do not use any sharp objects or abrasive materials when cleaning the bottle.
- Not to use water above 42°C (107F) to soak the plastic cap.
- Do not store BAS for a long period or transport it while its bottle is pressurized.