


Operation

- A) Opening/Closing bottle and filling insecticides:
- To open the bottle, holding the bottle cap then turning it counter clockwise.
- Follow insecticide's label instruction and fill the well mixed water or oil based insecticide into bottle. Avoid powder or any particle in the insecticide to prevent nozzle clogged.
- To close the bottle, holding and turning the bottle cap clockwise till tightening.

 Never open or close the bottle by turning the handle as this may damage

the handle seriously.



- B) Pressurizing the sprayer:
- pressing down then 1/4 turning the pump handle to unlock the pump handle
- pump plunger up and down until the required pressure is reached
- lock the pump handle

| C) Application rates of multi-nozzle (measured with water, at 2.8 bar, 40 psi): | : |
|---|---|
| fine fan360ml/min., 12.2 oz/min., 80 ° | |
| coarse fan, 80 ° coarse fan | |
| pin stream 330ml/min., 11.2 oz/min., 8m | |
| crack & crevice extension straw50ml/min.,1.7 oz/min. | |

Application rates of aerosol nozzle (measured with water, at 4 bar, 60 psi): fine, white ------60ml/min., 2 oz/min. medium, blue------90ml/min., 3 oz/min. coase, red ------130ml/min., 4.4 oz/min. crack & crevice tip ------115ml/min., 3.9 oz/min.

Repair and Spare Part

- do not modify the sprayer, this may cause a risk of harm and may damage the sprayer
- if any part shows signs of damage or wear, replace it immediately
- always use original spare parts for repair or maintenance